

# SMART VISION User Manual

(Application for Android Phone)

Sicunet Inc. www.sicunet.com

### Content

Content	2
Start	3
Installation	3
Connection	3
Monitoring	4
Monitoring Screen	4
Screen Division	4
PTZ	4
Preset	
Zoom	5
Option	5
Playback	6
Playback Screen	6
Playback Control	
Goto	6
	8
Search Screen	8
Recording Time Table	


### Start

### Installation

- 1 Run "Market" a or "Play Store"
- 2 In Search Window, write "SmartVision" and search
- 3 F SmartVision Installation

### Connection

In Site List, users can register and manage DVRs (Add/Edit/Delete).



\* In Account, users have to write exact registered User Name/Password in DVRs.

## Monitoring

### **Monitoring Screen**



### **Screen Division**

Can set Screen Division(Layout). (1x1, 2x2, 3x3, 4x4)



#### **PTZ**



In 1CH Full Screen, users can use PTZ . (For this, PTZ camera is installed and setup rightly in DVR)

#### **Preset**



In 1CH Full Screen, users can use PTZ [ ]. (For this, PTZ camera is installed and setup rightly in DVR)

### Zoom



Double ta	Zoom this Area
Drag h	Go to another Zooming Area
Spread &	Zoom-In
Pinch E	Zoom-Out

### Option




### Recording video transmission

When using this, users can get Network Streaming the same as Recording FPS in DVR.

\* When using this, Network Streaming can't reach Recording Video Streaming(in DVR), so we recommend to use <Network Stream> in Option.

# Playback

### **Playback Screen**



### **Playback Control**

Pause/Stop
Forward/Backward Playback
Fast Forward/Rewind

### Goto

### Select Date/Time

Prev. Hour

Go to Previous Hour

Playback

### Next. Hour

Go to Next Hour

### Goto First

Go to First Data.


### Goto Last

Go to Last(Final) Data.

### Search

### Search Screen

Search Click and go to Search Screen.



### **Recording Time Table**

Can check Record Data in Min/Hour/Day and search those Data.